

Power Steering Pump: Service and Repair Removal and Installation

Pre-removal Operation	Post-installation Operation
<ul style="list-style-type: none"> Power Steering Fluid Draining 	<ul style="list-style-type: none"> Power Steering Fluid Level Check Drive Belt Tension Check Power Steering Fluid Line Bleeding Oil Pump Pressure Test

AC904402 AB

REMOVAL STEPS <ol style="list-style-type: none"> PULLEY COVER DRIVE BELT PRESSURE SWITCH CONNECTOR EYE BOLT 	REMOVAL STEPS (Continued) <ol style="list-style-type: none"> PRESSURE HOSE GASKET SUCTION HOSE OIL PUMP OIL PUMP BRACKET
--	--

REMOVAL AND INSTALLATION

INSPECTION

- Check the drive belt for cracks.
- Check the pulley assembly for uneven rotation.